


Precast Concrete Stock Grid



HUDSON
CIVIL PRODUCTS

The Hudson Civil stock grid answers the call for a stock grid that meets all the expectations of land owners.

Constructed from a combination of durable concrete and galvanised steel rails, this stock grid will provide years of maintenance free service whilst actually stopping stock from passing over it.



You may expect all grids to perform the same but this grid provides unequalled performance:

- Durable high strength precast concrete
- Durable galvanised steel rails
- Removable rails for easy clearing of grid if required
- Smooth and quiet ride for vehicles
- Stops stock crossing the grid
- Drainage slots along the entire unit to remove stormwater
- Can be installed below ground or build up an existing roadway
- Threaded inserts allow posts to be bolted to grid for connecting any type of farm fence

Launceston Office:
7 Donald's Avenue Prospect,
Tasmania 7250
Phone: 03 6335 8200
Fax: 03 6340 1881



HUDSON
CIVIL PRODUCTS

Hobart Office:
9 Lampton Avenue, Derwent Park,
Tasmania, 7009
Phone: 03 6273 0463
Fax: 03 6273 3438

Precast Concrete Stock Grid



HUDSON
CIVIL PRODUCTS

Installation of a new Hudson Civil Stock Grid is very simple and will deliver years of trouble free performance if installed as recommended by Hudson Civil.

- 1 Prepare area by either excavating down to 500mm below existing roadway or leveling the site where the road is to be raised by 500mm.
- 2 Place a 100mm layer of 20mm crushed blue metal and level off (*no fines rock is recommended to assist drainage*).
- 3 Our truck will arrive at this stage and back up to the site. Sufficient room must be provided for our truck to manoeuvre to site and turn around close by.
- 4 Lower the grid using the trucks hi-ab crane and lifting chains supplied by us.
- 5 Place gravel around both road sides of the grid and compact well ensuring a smooth transition to the grid to stop gravel being dislodged by vehicles 'bouncing' as they drive on or off the grid.
- 6 Ensure that one side of the grid falls away to a drain to ensure water does not pond under or around the grid.
- 7 Connect your fence or posts to the grid.
- 8 Your grid is now installed and stock proof.

The example to the right shows a stock grid being installed in an area where the road is being lifted to the stock grids' height. These natural depressions are ideal locations for placing stock grids.

Hudson Civil Products Stock Grids are available through:



Launceston Office:
7 Donald's Avenue Prospect,
Tasmania 7250
Phone: 03 6335 8200
Fax: 03 6340 1881



HUDSON
CIVIL PRODUCTS

Hobart Office:
9 Lampton Avenue, Derwent Park,
Tasmania, 7009
Phone: 03 6273 0463
Fax: 03 6273 3438